

Connect PC with AED Trainer 2

USB to Serial Port Adapter – RS 232 (9 poles - with male connector)



AED Trainer 2

